


SXT80 Data Sheet 80x80x25mm DC Axial Fan

PROCOOL LLC Phone: 630-552-9999 email: service@procool.com www.procool.com






SXT80 Specif	ications
Rated Voltage	12.0 vDC
Voltage Range	10.2~13.8 vDC
Rated Current	0.17 A
Rated Power	2.04 w
Rated Speed	<1200-2400 RPM
Airflow	<14-32 CFM
Static Pressure	<2.52 mm H ² O
Noise Level, 1m, xyz axes avg	<6-14 dBA
Noise Level, 1m, z axis	<6-17 dBA
Operating Temperature	-10°/+70° C
Storage Temperature	-40°/+80° C
Bearing	Fluid Dynamic
Weight	2.8 oz

70° C

Pressure Curve



Temperature

30° C

This "RoHS Certificate" provides information regarding the absence of certain substances in the Fan model listed on this document.

MTBF Hours

L10

114223

The models identified below are in compliance with the European

Directive 2002/95/EC on the restriction of use of certain hazardous substances ("RoHS Directive"). The models do not contain any of the

substances referred to in the European Union Commission Decision of August18, 2006 (2005/618/EC) in connection with Articles 4 and 5 of the RoHS

Directive in concentrations in excess of the values permitted

For purposes of this RoHS Certificate, the maximum concentration values of the restricted substances by weight of homogeneous materials are:

hexavalent chromium 1,000 ppm poly-brominated biphenyls (PBB's) 1,000 ppm poly-brominated diphenyl ethers (PBDE's) 1,000 ppm cadmium 100 ppm

mercury 1,000 ppm lead 1,000 ppm

Conforms to CE - Reference 73/23/EEC Low Voltage Directive. Fan housing and fan blade resin flammability conforms to class UL-94V-2.




SXT80 Data Sheet 80x80x25mm DC Axial Fan

PROCOOL LLC Phone: 630-552-9999 email: service@procool.com www.procool.com

Operation:

Mount in desired location for optimal cooling. Intakes are best positioned lower or adjacent to equipment. Exhausts are best positioned at the top or above equipment.

Locate the temperature sensors (thermistors) on or near the heat source. The sensor tells the fan the temperature and will automatically start the fan at 77°F and run at the start speed of 1200 RPM. As temperature increases the fan speed will increase. The fan reaches full speed of 2400 RPM at about 104°F. Likewise, the fan will decrease in speed as the temp drops and will shut off when the temp falls below 77°F. This is illustrated in the fan speed chart.



The position of the temp sensor is critical to the operation of the fan. For less responsive operation the sensors can be moved away from the heat source. The sensor acts as a fine-tuning adjustment for the responsiveness of the fan.

Maintenance:

Cleaning the fan is the best preventative maintenance. Cleaning frequency would depend on the environment. It is recommended that the blade be cleaned to prevent any buildup of dust. Canned air works well.

Blade Removal:

For cleaning and maintenance, the blade prop can be removed.

Grasp the blade prop and pull straight out of the fan body. Inspect the shaft and lubricate if needed. Any oil will work; light grease works best. Clean blade as needed with a dry cloth. Soap and water can be used if needed, but should be thoroughly rinsed and dried before use. Reinstall the blade; when properly installed the blade will snap into place. Cleaning and inspection of the blade shaft should be done annually for best performance.

Warranty:

3 Years from the date of purchase.